



Wall framing
Cavity batten
Shadowclad

Metal saddle flashing under parapet capping. Refer E2/AS1 Figure 13 for min dimensions. Flexible flashing tape dressed up & adhered to building underlay behind battens

Rivet through sealant & seal capping to saddle flashing across top

Flexible flashing tape to extend min 50mm down face of battens
Parapet flashing with 5° min fall to interior side.
Building underlay to provide insulation of metal flashing to timber

Sloping packer with building underlay

Wall framing

Cavity batten

Building underlay continuous over top of wall framing

Note:

1. Treat all cut edges with Holdfast® Metalex® Clear

SC054: Shadowclad® Balustrade to Wall Junction (Cavity)