## Stud Building underlay Cavity batten Sheets to be fastened off independently of each other Cover batten 2mm expansion gap

Do not nail through weather grooves

Note:

SC010: Shadowclad® Vertical Joint with Optional Cover Batten (Cavity)