



Note:

1. Treat all cut edges with Holdfast® Metalex® Clear
2. 50mm strip of neutral cure silicon sealant must be provided at the termination point of all Z flashings at windows, corner boxes, etc.

SC030: Shadowclad® Jamb Detail (Cavity)