

Note:

2. Treat all cut edges with Holdfast® Metalex® Clear 1. Cut edges should be placed at the top of the sheet to avoid rain drips soaking into cut end grains

SC038: Shadowclad®Soffit Alternative Detail (Cavity)