



- Note:
1. Cut edges should be placed at the top of the sheet to avoid rain drips soaking into cut end grains
  2. Treat all cut edges with Holdfast® Metalex® Clear

SC038A: Shadowclad® Alternative Soffit Detail (Cavity)