

Plan

1. Allow 2mm expansion gap between flashing and cladding.

2. Treat all Shadowclad cut edges with Holdfast 

Metalex 

Clear

