



Use Sill Tape a minimum cover of 100 mm over the sheet surrounding the penetration is required

Pipe Minimum of 5° slope to the outside

Flexible tape banded minimum 25 mm around the pipe