



- Note:
1. Cut edges should be placed at the top of the sheet to avoid rain drips soaking into cut end grains
  2. Treat all cut edges with Holdfast® Metalex® Clear

SC050: Shadowclad® Basic Apron Flashing (Cavity)