



Shadowclad

Interior lining

Building underlay continuous around corner

Shadowclad 90° internal corner flashing

Ex25mm min timber cover boards with 6x6mm weather grooves.

Set cladding edge back 8mm to create drainage cavity

min cover

Note:

1. Treat all cut edges with Holdfast®Metalex®Clear
2. 50mm strip of neutral cure silicon sealant must be provided at the termination point of all Z flashings at windows, corner boxes, etc.

SC022: Shadowclad®External Corner with Cover Boards (Cavity)