



- Note:
1. Cut edges should be placed at the top of the sheet to avoid rain drips soaking into cut end grains
 2. Treat all cut edges with Holdfast® Metalex® Clear

SC035: Shadowclad® Soffit Detail (Direct Fix)