



- Shadowclad
- Building underlay folded into window opening and taped at corners
- Cavity battens
- Lintel
- Cavity spacers to enable fixing of Shadowclad at 150mm centres
- Additional building underlay from overlap above lapped over flashing
- 75mm min upstand cavity base closure vent strip. Position to give 15mm drip edge to cladding
- ▽ 15° Cross slope of Flashing
- Head flashing with 15° slope. 15mm high stop ends within cavity
- Seal and rivet angle to meter box and head flashing
- Packer
- Fit air seal over PEF rod around all sides of the box
- Metal meterbox

Vertical section

Note:

1. Treat all cut edges with Holdfast® Metalex®Clear

SC034A: Shadowclad® Meterbox Vertical Cross Section (Cavity)