



Vertical section

- Note:
1. Cut edges should be placed at the top of the sheet to avoid rain drips soaking into cut end grains
 2. Treat all cut edges with Holdfast® Metalex® Clear

SC044: Shadowclad® Upper Storey to Masonry Lower Storey (Cavity)