

# BAR012: Window Penetration Sill Tape Installation

Seal vertical joints by applying EcoPLY Barrier Sealing Tape over the joints

Lintel

Trimmer Stud

100 mm min turn-up to Flexible Sill Tape

Bottom Trimmer

Flexible Sill Tape turned out 50 mm min over plywood sheathing

